



DC Transformer Switch Wiring



<p>CONFIDENTIAL</p> <p>All information disclosed in this document is proprietary to BTX Window Automation. Holder agrees to maintain it in confidence and must not replicate or reveal this information in any manner.</p>	Project SWITCHES		 <p>BTXTM</p>		<p>BTX Window Automation 10880 Alder Creek Dallas, Texas 75224 (214) 343-9890 (214) 343-3444 FAX</p>	
	Dim INCHES				Title DC TRANSFORMER SWITCH WIRING DIAGRAM	
	Tolerances		Size A	Matl:	Dwg No: DC Trans Switch	Rev
	<p>XX ± .015 XXX ± .005 ANG ± .5°</p>		By: G. BENNETT	Date: 20-FEB-00	Scale: NTS	Sheet 1 of 1